25X1

FROM: START
TO: H-24 (*1130*)

TIME (NLT)	RESP	ACTION	COMPLETED
ASAP	DCOC	Complete & distrubute mission alert notification	*0730L*
ASAP	DCOC	[ ] Acknowledge Receipt of [ ]	*0715*	25X1
ASAP	DCOC	Convert H -hour time to local and record in check list.	*0930L*
ASAP	DCOC	Complete pilots activity schedule (5) (1-DCO, 1-M/C, 1-Flt Surg, 1-CO, 1-DCOL)	*0745L*
ASAP	DCOC	Notify & alet the C-130 [ ]	*0730 L*	25X1 25X1

25X1

Advise that we have an airlift requirement [ ] at *511745L*. In place time here to pick up TAKE is L+2:00. *04/1050* | 25X1

| ASAP | DCOC | Check with DCOM to see if Msgs [ ] have been received by [ ] prior to H-24. | *-1110* | 25X1 25X1 25X1 |

25X1

| ASAP | DCOC | Check with DCOM FOR the check list to be used. | *1100* |

(a) Custom or canned route.

ILLEGIB

| ASAP | TTFC | Delivers tanker schedule with all C/S - & timing. | *1415* |

Page 1

revised 16 Sept 67.

FROM: H -24:00(_1130_ L)

TO: H -18:00(_1730_ L)

TIME NLT	RESP	ACTION	TIME
H -~~███████████████████████████████~~			
H -23:30(_1200_ L)	DCOC/	M/C attend Commander's initial briefing. Receive Ops personnel inputs for recovery team. Give to DCS. Prepare access lists for CP and Flt Following Room.	_N/R_
H -23:00(_1230_ L)	SEC	Hangars secured, access lists posted.	_1230_
25X1 H -22:00(_1330_ L)	COMMO	[███] Prepare Flimsy	_0654L_
H -21:00(_1430_ L)	Flt Surg	Results of pilot physicals	_0900 L_
25X1 H -21:00(_1430_ L)	DCOC	Send [███]	_1120 L_
H -20:30(_1500_ L)	COMMO	Notify DCM of Freq Channelization and translator code.	
H -19:00(_1630_ L)	DCM	Complete TEB and Refuel (Item 8) #1 _1506_ * (Item 3) #2 _1900_	
H -19:00(_1630_ L)	SEC	Advise M/C of Seat Kit No. Prm AC Kit _119_ (Enter Bottom or [███] Sec AC Kit _105_ 25X1	
H -19:00(_1630_ L)	DCOM	Tape Recorders ready in briefing Rm _1500_	
H -19:00(_1630_ L)	COMMO	Complete Commo flimsy, cys to: M/C-3, (2 Pilots + 1 CP) and DCOMF-2	_1430_

* DCM REGENERATION

Revised 25 August 1967

FROM: H-18:00 (_1730_ L)

TO: H-12:00 (_2330_ L)

TIME (NLT)	RESP	ACTION		TIME
H-18:00(_1730_ L)	DCOMI	Start Intelligence Briefing		_1530_
H-17:00(_1830_ L)	DCO	Supervise Plt's Initial Briefing		_1600_
H-16:00(_1930_ L)	DCM	Complete INS pre-flt (item 12)	#1	_1800_
			#2	_NA_ 25X1
H-15:00(_2030_ L)	DCOM(A)	Receive [ ]		_1050 L_
H-15:00(_2030_ L)	DCM	Deliver [ ] Checkout Info.		_NR_
H-15:00(_2030_ L)	COMMO	Deliver [ ] to M/C if all Info available.		_1645_ 25X1
H-13:00(_2230_ L)	DCM	Complete [ ] (Item 13)	#1	_1500_ 25X1
			#2	_1900_
H-13:00(_2230_ L)	DCOM(A)	INS Load Sheet. Deliver to INS		_2200_
H-13:00(_2230_ L)	Flt Surg	Start Crew Rest		_2200_
H-12:30(_2300_ L)	DCOM	Notify M/C of receipt of [ ] (Pkg Data) [ ]	25X1 / 25X1	_1110 L_
H-12:00(_2330_ L)	DCOC	Send [ ] Support Msg to [ ]		_1445 L_
H-12:00(_2330_ L)	DCOM(A)	Receive Wea update flt plan [ ]		_0145_

25X1

25X1
25X1

FROM: H-12:00 (_2330_ L)

TO: H- 2:00 (_0930_ L)'

TIME(NLT)	RESP	ACTION		TIME
H-11:30(_2400_ L)	DCOM	Package program to Pkg personnel		0200
H- 9:00(_0230_ L)	DCOW	▬ M/C item (G) <u>Wx effect</u> of ability to launch. ☐		1254
H- 9:00(_0230_ L)	DCOC	Send ☐ to Hqs		1254
H- 8:30(_0300_ L)	DCM	Complete Pkg Load (Item 15)	#1	1730
			#2	1845

25X1 (left of DCOC row)   25X1 (right of Wx row)

ILLEGIB

H- 4:30(_0700_ L)	DCOM(A)	Film strip complete		0555
H- 4:00(_0730_ L)	AFCS	Report Equip status to DCOC		0640
H- 3:45(_0745_ L)	CMDR DCO F/Surg	Final decision on primary & spare pilot, notify DCOL		0745
H- 3:45(_0745_ L)	DCO	Current Airfield Status		0745
H- 3:30) _0800_ L)	DCM	Start INS Warm (Item 21)	#1	0800
		*(Item 14)	#2	0800
H- 3:30(_0800_ L)	DCO	Final Briefing		0800
H- 2:30(_0900_ L)	DCOC	Send ☐ confirmation of Coord.		04/2309

25X1 (left of last two DCOC-related rows)

* DCM REGENERATION

FROM: H -2:00 (*0930* L)

TO: L HOUR (*1130* L)

TIME (NLT)	RESP	ACTION	TIME
H -1:30(*1000* L)	DCOC	Notify Helicopter Section of ETD (CONTROLLER)	*0955*
H -2:00(*0930* L)	DCOMI	E&E Packet turned in to DCOL	*1000*
H -1:35(*0955* L)	DCOW	Letdown plates to pilots	*0840*
H -1:20(*1040* L)	F/Surg	Pre-suiting physical	*1010*
H -1:00(*1030* L)	DCOM	Load DCOM material both acft	#1 *1045* #2 *1045* *1035*
H -0:50(*1040* L)	DCOL	Pilot to aircraft	*0946*
H -1:00(*1030* L)	DCO	Go-No-Go decision	*1000*
H -1:00(*1030* L)	DCOC	Activate HF (CONTROLLER)	*1030*
H -1:00(*1030* L)	DCOC	Check latest NOTAMS	*1000*
H -1:00(*1030* L)	DCOC	Assure Chopper alerted	*1045*
H -:45(*1045* L)	DCOL	Pilot hooked up in acft	*1058*
H -:30(*1100* L)	DCM	Start engine	*1115*
H -:15(*1115* L)	DCOC	Cmdr's emerg C.L., Dash-1, CYG Ck list, ⬚ in place	*1130*
H -:00(*1130* L)	DCOC	Send ⬚	*1130*
H Hour(*1130* L)	DCOC	Send T/O Msg to ⬚	*1245*
H +1:15(*1245* L)	DCO	Release spare (primary)	*1500*
:30 prior to ldg	DCOC	Alert chopper (controller)	*1500*
:30 prior to ldg	DCOC	Notify Transit Alert (controller)	*1430*
:30 prior to ldg	M/C	Prepare ⬚ for DTFC or DCO (clip bd) (primary)	*1540*
ASAP after ldg	DCOC	Send ⬚ (Msn ldg report)	*1640*
ASAP after ldg	DCOC	Send ⬚ (M/A) Msg	

25X1 (annotations in right and left margins)

*(**

FROM: 25X1 L)

TO: END

TIME (NLT)	RESP	ACTION	TIME
		SECONDARY LAUNCHED	
25X1 ASAP	DCOC	Send [ ] on Primary	NR
ASAP	DCOC	Send [ ] abort Msg on Prim	NR
H +1:00(_____L)	DCOC	Send [ ] on Secondary	NR
25X1 H +1:00(_____L)	DCOC	Send [ ] T/O on Secondary	NR
L -:30(_____L)	DCOC	Notify Helicopter (controller)	NR
L -:30(_____L)	DCOC	Notify Trans Alert (controller)	NR
25X1 L Hour(_____L)	DCOC	Send [ ]	NR
L Hour(_____L)	DCOC	Send [ ] Canx - Give ATA	NR

****

ASAP after ldg	DCOC	Receive CYG Down time, then release Strip Alert/Airborne Alert Tnkr. Notify TTFC.	1540
ASAP after ldg	DCOC	Release Helicopter (controller)	1540
ASAP after Ldg	DCOC	Release C-130 [ ]	1540
L +:30(_____L)	AFCS	Shutdown	1600
25X1 L +1:30(_____L)	DCOMI	Par "C" of [ ] to DCOM	
L +3:30(_____L)	SEC	Sterilize aircraft	
L Plus (_____L)	DCOC	Release Acft to DCM	
L +4:00(_____L)	DCOM	Recording tape and film strip to Security.	
L +5:00(_____L)	DCO	Review Tanker Msn Report	
L +5:00(_____L)	DCOM	Tape of debrief to Security	
25X1 L +5:00(_____L)	COMMO	[ ]	

25X1

Revised 23 August 1967

25X1

Next 1 Page(s) In Document Exempt